


Wheel Hanger Installation



Find stud in wall with stud locator. (Not provided)
Center plate, with tube angling up, over stud for locating holes.

(2) Screws are provided.

STOP

- 1. DO NOT OVER-TIGHTEN BOLTS! DOING SO MIGHT STRIP THREADS FROM STUD!**
- 2. IF FOR ANY REASON PARTS ARE MISSING DUE TO SHIPPING PLEASE CALL: 1-800-568-7423 EXT 188**

